


Assembly Instructions

Dining-table

Precautions:

1. It is recommended to wear gloves for assembly to protect hands from injury,
2. When assembling, please strictly follow the installation direction and order in the instruction manual.
3. Tighten the screws after two or more parts have been successfully assembled, Tightening the screws early will cause the parts to be disassembled and reassembled.
4. Please place all parts correctly to avoid unnecessary trouble.

Thank you for your patience in reading,. Wish you a happy life!




"SAFETY TIPS:


Static charge may cause dust on foam – clean with a dry or damp cloth. Small foam strands may be present – handle gently and dispose of properly.

Do not burn or incinerate. Check local recycling guidelines."

Explosion Diagram




Parts and Operation Elements




①

2Pcs




②

1Pcs




③

2Pcs




④

2Pcs



⑤






2Pcs




⑥

2Pcs


HardWare

 M6*15	 M6*35	 M6*60	 Cam Bolt
A 10PCS +2PCS	B 4PCS +1PCS	C 16PCS +2PCS	D 8PCS +2PCS
 Ø 15*11 Cam Lock	 Ø8*40 Dowel	 Ø30*28	 36*16
E 8PCS +2PCS	F 4PCS	G 6PCS	H 4PCS
 M5*15	 40x40x15	 4#	
J 8PCS +2PCS	K 4PCS	L 1PCS	M 1PCS
	 SPARE BAG		
N 8PCS +2PCS	1PCS		
⚠ Tips: The number after "+" represents the spare hardware.			




1



Dx4




Fx4



Note:If you encounter any issues,please contact customer service.

2



Note: If you encounter any issues, please contact customer service.


3



Ex4




Mx1




Hardware installation demonstration



When inserting cam ensure arrowhead on cam points toward to the hole on the panel edge




Note: If you encounter any issues, please contact customer service.

4



	
Dx4	Hx4
	
Mx1	Jx8




Note: If you encounter any issues, please contact customer service.

5




Ax6



4#

Lx1



This step requires two people to complete

Note:If you encounter any issues,please contact customer service.



4#


This diagram illustrates the exploded view of the frame assembly. It shows two vertical rectangular frames (4) connected by two horizontal bars (5). The frames are also connected to two horizontal bars (6). The assembly is secured with screws (C) and a lock (L). The exploded view shows the relative positions of the components and the path of the screws and lock.

10

7




Ax4




4#

Lx1



Note: If you encounter any issues, please contact customer service.

8




Note:If you encounter any issues,please contact customer service.


9



Bx4




Cx8



4#

Lx1



Note:If you encounter any issues,please contact customer service.


10



Ex4




Mx1



Hardware installation demonstration

When inserting cam ensure arrowhead on cam points toward to the hole on the panel edge



Note:If you encounter any issues,please contact customer service.


11



Gx6




Nx8




Note: If you encounter any issues, please contact customer service.

12



Kx4



— installation is complete —

Note: If you encounter any issues, please contact customer service.