


Five Drawer Dresser



DJ1099-70CM






IMPORTANT INFORMATION!

please read the entire manual before starting to assemble and/or using this product. follow the manual thoroughly and keep it for further reference.





AVOID SCRATCHES!

In order to avoid scratching this furniture should be assembled on a soft layer—could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !

Overtured furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

IMPORTANT !

It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months - in order to assure stability through-out the lifespan of the product.


For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag. For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.

Please use proper tools for assembly. Using an electric screwdriver can accelerate the assembly speed, but please do not overtighten the screws.


SAFETY TIPS !

Static charge may cause dust on foam - clean with a dry or damp cloth. Small foam strands may be present — handle gently and dispose of properly. Do not burn or incinerate. Check local recycling guidelines.


Board Identification




PARTS LIST




① X1




② X1




③ X1




④ X1




⑤ X1




⑥ X1




⑦ X1




⑧ X1




⑨ X1




⑩ X1




⑪ X1




⑫ X1




⑬ X1




⑭ X1




⑮ X1




⑯ X2




⑰ X5




⑱ X5



⑲ X5




⑳ X5




㉑ X5


PARTS LIST



②② X5




②③ X1





②④ X2



②⑤ X1



Please prepare the following tools



When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size


Tips: The number after "+" represents the spare hardware.

A x 79




Ø15 X 9.5 mm

B x 63



Ø7 X 40 mm

C x 18




Ø 6 x 30 mm

D x 70



Ø3.5 X 14 mm

E x 5




Ø 4 x 15 mm

F x 2



Ø3.5 X 12 mm

G x 1



H x 10




H-1




H-2

J x 14




Ø5 X 40 mm

K x 16



Ø7 X 40 mm

L x 30




Ø4 X 35 mm


M x 79



N x 6



P x 1



Q x 2



R x 2



R-1



R-2




R-3



R-4

x 5

350mm



CL

CR

DL




DR

+ 2




SPARE BAG






Please note during installation that the distance between the edges of the board is small, and it is the straight opening direction of the plastic particles. Do not install it incorrectly!






1

A x 4  Ø15 X 9 5 mm	C x 4  Ø 6 x 30 mm	K x 4  Ø7 X 40 mm	
--	---	--	---




Pay attention to the installation direction, as shown in the diagram!

2








Remove the film before pasting,
but do not remove the double-sided
sticky tape together!





- a) the product contains non-replaceable batteries;
- b) Battery type(CR2025)
- c) Nomlnal voltage: (3-5V)




3

C x 2  Ø 6 x 30 mm	K x 2  Ø7 X 40 mm	A x 2  Ø15 x 9.5 mm	
---	--	--	---








4

A x 6  Ø15 x 9.5 mm	B x 6 (Blue)  Ø7 X 40 mm	
--	---	---









5

J x 6  Ø5 X 40 mm	C x 2  Ø 6 x 30 mm	
--	---	---




6





A x 10  Ø15 X 9 5 mm	C x 4  Ø 6 x 30 mm	K x 10  Ø7 X 40 mm	
---	---	---	---






7




8




C x 2  Ø 6 x 30 mm	J x 8  Ø 5 X40 mm	R x 2  R-1  R-2	B x 4  (Blue) Ø7 X 40 mm	
---	--	--	---	---





Screw R-2 can not lock hardware R-1 tight




Bx4



JX8



C



6


CX2

4


7





3

9




10


A x16  Ø15 x 9.5 mm	B x4  (Blue) Ø7 X 40 mm	
--	---	---





11




12

A x 12  Ø15 x 9,5 mm	N x 6 	
---	--	---



13






14




A x 4



Ø15 x 9.5 mm






15





16

R x 2



⚠ Warning: If you overturn the furniture, it may cause serious or fatal crushing injuries. We have a wall connection device attached, please use it to hold the furniture following these instructions.

1. Mark the corresponding hole positions where you want to place the furniture;
2. Use a impact drill to drill holes and pay attention to avoid wires and water pipes;
3. Knock the expansion pipes into the wall holes;
4. Place the furniture in the corresponding position and tighten the wall connection device with screws, and lock the **R-2** screw tightly.





17




L x30




Ø4 X 35 mm




18

D x 30  Ø3.5 X 14 mm	DL x 5  350mm	DR x 5  350mm	
---	--	--	---








x5



x5

19


A x 25  Ø 15 x 9.5 mm	B x 25 (Blue)  Ø 7 X 40 mm	E x 5  Ø 4 x 15 mm	
--	--	---	---





20

Mx79 	Q x 2 	
---	--	--


Cabinet Slide



Drawer Slide




Peel off the protective film first and stick it well.




Stick the ring patch M on the lock holes!


-LED lamp with effective remote control distance of 5 meters



1.Take out the remote control gasket



2.Align remote controller to the RGB Control box to adjust the color mode



- Installation complete.

APP PROGRAM USAGE




Scan two-dimensional code download APP

- ① Connect LED color strip and controller, power on controller
- ② Scan two-dimensional code download APP:



- ③ Start APP, search and connect controller
- ④ Enjoy the Bluetooth wireless control experience



Notes:
detailed operating instructions,
enter the menu "Guide":

Product Paramters:

- Bluetooth: BLEV4.2
- Input Voltage:4.5~26V
- Working Temp:-25~75°C
- Size:43*22*11mm
- Weight:30g
- Max Power:144W(24V)

LED mobile phone Bluetooth controllerProduct Features

- LED Bluetooth controller is directly via mobilephone control remote distance can reach 20m without the need to set up, easy to connect open the software within 5 seconds you can automatically connect the controller
 - Flow the rhythm of the music changes
 - Group control
 - Brightness, speed addition and subtraction
 - Maximum can be 10 meters RGB(W) strip
 - The software shows that the text is based onthe language of the mobile phone set up automatic transformation of Chinese and English
- Animation Effect:
- Colorful gradient
 - All kinds of monochrome, double color gradient
 - All kinds of monochrome, double color,colorfull flashing
 - Colorful jump
 - Follow the thtyhm of the music chagnes